



Zündverteiler  
Ignition Distributors  
Allumeurs  
Distribuidores de encendido

0 231 116..

Ablegen in/ File in  
Classer dans/ Clasificar en VDT-EVE 121/0

No.	1	2	3	4	5	6	⑩
Zündverteiler	Kontaktsatz	Kondensator	Verteilerläufer	Verteilerkoppe	U-Druckversteller	U-Brecherplatte	Teilesatz
	1 237 013... ZKB..	1 237 330..	1 234 332..	1 235 522..	1 237 121..	1 230 090..	1 237 010..

0 231 116 001	..6	..006	..052	..070	..109	..102	-	..012
005	7	007	052	070	109	102	-	012
006	7	007	052	088	109	102	-	012
007	7	007	052	088	109	102	-	012
008	7	007	054	088	523012	105	-	012
009	7	007	054	088	012	105	-	012
010	7	007	052	070	522109	102	-	012
011	7	007	052	070	109	102	-	012
012	7	007	052	088	109	127	-	012
013	7	007	052	088	109	127	-	012
014	7	007	052	088	109	102	-	012
015	7	007	052	088	109	102	-	012
017	7	007	052	070	109	102	-	012
018	7	007	052	088	109	102	-	012
019	7	007	052	088	109	102	-	012
020	7	007	052	088	109	137	-	012
021	7	007	052	088	109	137	-	012
022	7	007	052	088	109	137	-	012
023	7	007	052	088	109	137	-	012
024	6	006	052	070	109	117	-	012
025	6	006	052	070	109	102	-	012
026	7	007	052	070	109	138	-	012
027	7	007	052	070	109	138	-	012
028	7	007	052	088	109	138	-	012
029	7	007	052	088	109	138	-	012
030	7	007	052	088	109	137	-	012
033	7	007	067	088	109	142	-	012
034	7	007	067	088	109	142	-	012
037	7	007	067	070	109	145	-	012
038	7	007	067	062	109	145	-	012
039	7	007	067	070	109	142	-	012
040	7	007	067	088	109	142	-	012
041	7	007	067	070	523018	140	-	012
042	7	007	067	062	522109	142	-	012
046	7	007	067	062	109	142	-	012

ROBERT BOSCH GMBH STUTTGART

Printed in Germany - Imprime en Allemagne Rep. Fed. par  
Robert Bosch GmbH, Hauptdruckerei

No.	1	2	3	4	5	6	⑩
Zündver- teiler	Kontakt- satz	Konden- sator	Verteiler- läufer	Verteiler- kappe	U-Druck- versteller	U-Brecher- platte	Teilesatz
	1 237 013.. ZKB..	1 237 336..	1 234 332..	1 235 522..	1 237 121..	1 230 090..	1 237 010..

0 231 116 047	..27..	027	..067	..062	..060	..301	-	..012
048	7	007	067	088	060	145	-	012
049	7	007	067	088	060	142	-	012
050	7	007	067	088	060	142	-	012
051	27	027	067	088	060	301	-	012
052	83	083	067	088	060	145	-	012
053	44	044	116	074	060	325	-	012
054	62	062	202	074	060	321	-	012
055	44	044	156	074	194	341	-	012
056	44	044	156	074	194	263	-	012
057	44	044	156	074	194	263	-	012
058	44	044	156	074	194	263	-	012
059	44	044	156	074	194	341	-	012
060	62	062	171	074	060	369	-	012
061	82	082	178	109	060	403	-	012
062	59	059	181	109	060	403	-	012
063	44	044	156	074	194	341	-	012
064	44	044	156	074	194	341	-	012
065	44	044	156	074	194	341	-	012
066	82	082	198	109	060	403	-	012
067	82	082	198	109	060	403	-	012
068	82	082	198	109	060	457	-	012
069	44	044	237	074	194	443	-	012
070	44	044	228	074	194	341	-	012
071	44	044	228	074	194	341	-	012
072	44	044	237	074	194	341	-	012
073	44	044	237	074	194	341	-	012
074	44	044	156	074	194	335	-	012
075	44	044	228	074	194	335	-	012
076	44	044	228	074	194	335	-	012
077	44	044	237	074	194	335	-	012
078	44	044	237	074	194	335	-	012